

**A151.300****A151.600****Bedienungsanleitung****Toast-/Überbackgerät**

Seite 1 bis 12

D/A/CH**Instruction manual****Quartz tube toaster**

from page 13 to 24

GB/UK**Mode d'emploi****Toaster et appareil à gratiner**

de page 25 à page 36

F/B/CH**Gebruiksaanwijzing****Toast-/bovenbakapparaat**

blz. 73 t/m 84

NL/B**Instrukcja obsługi****Toster/Opiekacz**

strony od 121 do 132

PL

1. General Information	14
1.1 Information about the instruction manual	14
1.2 Key to symbols	14
1.3 Liability and Warrantees	15
1.4 Copyright protection	15
1.5 Declaration of conformity	15
2. Safety	16
2.1 General information	16
2.2 Safety instructions for use of the device	16-17
2.3 Intended use	17
3. Delivery, packaging and storage	18
3.1 Delivery check	18
3.2 Packaging	18
3.3 Storage	18
4. Technical data	19
4.1 Technical specification	19
4.2 Overview of parts	19
5. Installation and operation	20
5.1 Safety instructions	20
5.2 Installation and connection	21
5.3 Operating	21-22
6. Cleaning and maintenance	23
6.1 Safety advice	23
6.2 Cleaning	23
6.3 Safety instructions for maintenance	23
7. Waste disposal	24

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120

1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.



WARNING! Hot external surface!

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General Information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

- The device is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the device.
- Children should be observed to ensure that they are not playing with the device.
- Preserve this manual safely. When passing on/selling the device to a third party, the manuals must be handed over along with the device.
- Every person using the device must act in accordance to the manuals and under consideration of the safety advice.
- The device is to be used indoors only.

2.3 Intended use

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

Quartz tube toaster is only meant for quick roasting, defrosting deeply frozen products, toasting (pizza, quiches, baguettes, hamburgers etc.) and roasting without previous heating of the device.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt.

In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly. If required refresh or renew.


4. Technical data

4.1 Technical specification

Name	Quartz tube toaster	
Item number	A151.300	A151.600
Model:	single	double
Made of:	Stainless steel	
Temperature:	up to 250°C	
Time switch:	0 – 15 min.	
Terminal power:	230 V ~ 50 Hz 1,7 kW	230 V ~ 50 Hz 3,0 kW
Outer dimensions:	W 440 x D 260 x H 290 mm	W 440 x D 260 x H 400 mm
Inner dimensions:	W 355 x D 240 x H 50 mm	W 355 x D 240 x H 2x 50 mm
Weight:	8,2 kg	9,7 kg
Accessories:	1 grill grate, 1 toast tongs	2 grill grates, 1 toast tongs

Subject to technical changes and alterations!

4.2 Overview of parts



5. Installation and operation

5.1 Safety instructions



WARNING! Electrical hazard!

The device must only be connected to a properly installed single socket with protective contact.

Never yank cord to disconnect from outlet.

Cable must not touch any hot parts.

- See that the cable does not touch any heat sources or sharp edges. Do not let the cable dangle over the counter edge.



WARNING! Hot surface!

During operation some elements of the device very become hot. To avoid burns, do not touch hot elements!

- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- Do not move or tilt the device when in operation.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection

- Discard the complete packing material after unpacking the device.
- Remove the protective plastic wrap from the outer walls. It is important to make sure that the remains of glue do not remain. In case such remains do remain, remove them with a suitable solvent.
- Place the device on top of an even and safe surface which supports the weight of the device and is not heat sensitive.
- **Not at any time** should you place the device on an inflammable surface (such as: table cloth, carpet, etc.).
- You must not position the device near open fireplaces, electric ovens/arc furnaces, furnaces/electric heaters or other heat sources.
- Do not place the unit near flammable or easily ignitable materials.
- To ensure best results, make sure the device has no other objects within a space of 10 cm from its sides and 30 cm from the front and back. A space of 30 cm should also be left above the device, e.g. between the device and the bottom of the next shelf.
- Place the device so that air can flow freely through the ventilation ducts.
- **Never** put any objects on the toaster.
- The electrical circuit in the socket must be secured to at least 16A. Only connect the unit directly to the wall socket; do not use any extension cords or power strips.
- Place the device so that the plug is easily accessible and can be quickly removed from its socket in case of necessity.

5.3 Operating

- Before first use clean the surface of the device with a soft and damp cloth and a mild cleaning agent.
- Clean the removable grill grate and toast tongs with warm water and a mild cleaning agent, rinse the grill grate with clean water and dry it with a soft and dry cloth before putting it back into the device.
- Clean the protective grillwork inside the device with a damp cloth in order to remove the dust formed during the transportation.
- Connect the device to a suitable single power socket.
- Before first use start the device for about 10 minutes. During the first use the heat insulation may cause the formation of smoke and unpleasant smells may be given off.
- The device is equipped at the top and at the bottom with infrared quartz heating bars. Infrared heaters can be started together or separately. The double toaster is additionally equipped in the middle with infrared heating bars.

- Set the required mode with the use of the revolving adjuster for upper/lower heating and a suitable roasting time with the use of the time switch (0-15 min).
- In the case of the double toaster there is a possibility of using both levels and preparing a larger number of dishes at the same time.
- Put the dishes in quartz tube toaster. They can be put directly on the protective grillwork or an enclosed grill grate can be used for this. The grill grate handle makes taking dishes out easier.



WARNING! Danger of burn!

During the work of the device its surface and the grill grate handle heat up very much. Use kitchen protective gloves to put and take dishes out!

- When the adjusted time has elapsed, an acoustic signal will resound. The device will switch off automatically.
- The roasting process can be stopped any time by switching the time switch to the „0“ position and the revolving adjuster for upper / lower heating to the „OFF“ position.
- Take the ready dishes out carefully.
- Leave the device to cool.
- Empty the crumbs drawer regularly. It is placed above the operation panel.



WARNING! Danger of burn!

The crumbs drawer handle heats up very much during the work of the device. First leave the device to cool and only then take the drawer out.

- The crumbs drawer should be taken out with the use of the handle and emptied. If necessary, clean it with a soft and damp cloth and finally dry.
- If the device is not going to be used any more, disconnect it from the current generator (take out the plug!).

6. Cleaning and maintenance

6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power socket (pull the power plug!!!) and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



CAUTION!

The device is not suited for direct washing via water jets. Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning

- Clean the device regularly.
- All the accessories (the grate, the tongs and the crumbs drawer) should be cleaned with a mild cleaning agent, rinsed thoroughly with clean water and finally dried.
- The protective grillwork should be cleaned regularly with a soft and damp cloth.
- In the case of stubborn dirt on the protective grillwork take it out and clean it with warm water and a mild cleaning agent. Then rinse it thoroughly with clean water and dry.
- Clean the casing of the device with a soft and damp cloth.
- Use soft cloth only and make sure you **never** use any kind of abrasive agents or pads, which could scratch the surface.
- After the cleaning procedure you should use a soft and dry cloth to wipe dry and polish the surface.
- Make sure the device has been cleaned and dried properly for further usage.

6.3 Safety instructions for maintenance

- Check the mains connection cable for damage from time to time. Never operate the device when the cable is damaged. A damaged cable must immediately be replaced by customer service or a qualified electrician to avoid dangers.
- In case of damage or malfunction, please contact your stockist or our customer service centre. Pay attention to the troubleshooting tips in pt. 7.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

7. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



NOTE!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120