



100085

Bedienungsanleitung Thermo-Transportbehälter 20L

D/A/CH

Instruction manualThermo transport container 20L

GB/UK

Mode d'emploi Conteneur isotherme 20L pour le transport des aliments

F/B/CH

Gebruiksaanwijzing Thermisch transport container 20L

NL/B

Instrukcja obsługi Pojemnik termoizolacyjny do transportu 20L

PL

Инструкция по эксплуатации Термоконтейнер 20L

RUS

Інструкція обслуговування Термоконтейнер 20L

UA





Technical information:

Name: • Thermal transport container, 20L

with spout and shield

Art. no.: • 100085

Construction: • chrome-nickel steel 18/10, brushed

double walls

lid with 4 latches and silicone seal

• 1 handle for carrying, 1 side handle for tipping

aeration valve

stackable

Capacity: • 20 litres

Dimensions: • Ø 420 mm, H 340 mm

Weight: ● 7.1 kg

The thermal transport container is intended for transport of both cold and hot liquids and food products.

Diagram of parts



- Carrying handle
- 2 Lid
- ③ Upper handle
- (4) Pressure valve
- 5 Latches
- 6 Tank
- (7) Spout
- (8) Spout shield



Tips for the user

- Unpack the thermal container and remove all packing material.
- Open the latches and remove the lid from the container.
- Prior to using and after every use, wash the container and lid thoroughly in warm water with a mild cleaning agent approved for food service applications.
- Rinse with clean water and leave the unit to dry, or wipe dry with a soft cloth.
- Regularly clean the spout by running a small amount of water with cleaning agent through it, then clean water.
- Always use soft cloths, never use harsh cleaning substances that may scratch the surface.
- The external surface of the transport container may be cleaned using commercially available substances for stainless steel.
- Ensure that the spout is closed and fill the container with cold or hot fluids or food products (max. 20 litres), replace the lid and secure it using the latches to ensure safe transport.

or

The double-wall construction ensures proper insulation.
Heat loss is approx. 6℃ per hour.



The desired amount of liquid as needed can be taken from the container through the spout (press down)



from the top, after releasing the latches and removing the lid from the container. The desired amount of liquid or food product can be taken by tipping the container. Use the carrying handle and side handle.

Bartscher GmbH Franz-Kleine-Str. 28 D-33154 Salzkotten Germany

phone: +49 (0) 5258 971-0 fax: +49 (0) 5258 971-120