



100080

Bedienungsanleitung

Thermo-Transportbehälter 20L

D/A/CH

Instruction manual

Thermo transport container 20L

GB/UK

Mode d'emploi

Conteneur isotherme 20L
pour le transport des aliments

F/B/CH

Gebruiksaanwijzing

Thermisch transport container 20L

NL/B

Instrukcja obsługi

Pojemnik termoizolacyjny do transportu 20L

PL

Инструкция по эксплуатации

Термоконтэйнер 20L

RUS

Інструкція обслуговування

Термоконтэйнер 20L

UA

Technical information:

Name:	<ul style="list-style-type: none">• Thermo transport container 20L
Article number:	<ul style="list-style-type: none">• 100080
Construction:	<ul style="list-style-type: none">• Chrome-nickel steel 18/10, brushed• Lid with four latches and silicon seal• 1 handle, 1 side swinging handle• ventilation duct• stackable
Capacity:	<ul style="list-style-type: none">• 20 litres
Dimensions:	<ul style="list-style-type: none">• Ø 370 mm; H 340 mm
Weight:	<ul style="list-style-type: none">• 6.0 kg

Parts

- ① Latch
- ② Handle
- ③ Container
- ④ Swinging handle
- ⑤ Lid
- ⑥ Ventilation duct

The thermo transport container is intended for **transporting** cold and warm liquids and food products.

Tips for the user

- Unpack the thermo transport container and remove all packing material.
- Loosen the latches and remove the lid from the container.
- Wash the container and lid with silicon seal in warm water and with a mild cleaning agent before and after use.
- Rinse in clean water and leave to dry, or wipe dry with a soft cloth.
- Use only soft cloths and never use any abrasive cleaners that could scratch the surface.
- Use commercially available stainless steel cleaning agents for cleaning the exterior of the transport container.
- Fill the clean thermo transport container with a desired hot/cold liquid or food product (maximum 20 litres), cover with the lid and secure using the latches. These ensure safe transport of the container's contents.
- The transport container's double walls ensure proper isolation. Heat loss amounts to approx. 6°C per hour.
- Open the container and pour out the desired amount of liquid or take out the desired amount of food as needed. To empty the thermo transport container, use the handle and side swinging handle (see diagram at right).



Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120